
-


-


Lvl 5 - Wall Plate Level
8670
2890
Lvl 4 - Second Floor Level
5780
2890
Lvl 3 - First Floor Level
2890
2890
Lvl 2 - Ground Floor Level
0
Lvl 1 - Foundation Level
-2100


Lvl 5 - Wall Plate Level
8670
Lvl 4 - Second Floor Level
5780
Lvl 3 - First Floor Level
2890
Lvl 2 - Ground Floor Level
0
Lvl 1 - Foundation Level
-2100






Lvl 5 - Wall Plate Level
8670
Lvl 4 - Second Floor Level
5780
Lvl 3 - First Floor Level
2890
Lvl 2 - Ground Floor Level
0
Lvl 1 - Foundation Level
-2100


Lvl 5 - Wall Plate Level
8670
Lvl 4 - Second Floor Level
5780
Lvl 3 - First Floor Level
2890
Lvl 2 - Ground Floor Level
0
Lvl 1 - Foundation Level
-2100